



STEPS

- Attach open pipe clamp to wood.
- 2 Attach wood to wall.
- 8 Fill mason jar with rocks first, fill soil almost to top of jar rim, plant succulent in soil.
- 4 Hold jar in place against wood and tighten pipe clamp around jar.



Photo source and more details on installation, visit http://the3rsblog.wordpress.com/2014/02/09/ hanging-mason-jar-planter/



HOMES

